

Installing software on TRT

1. Close the TRT program by logging in
 - a. Go to system
 - b. Terminate, and close the black window that appears
2. Unplug the black USB on the back of the computer and plug in the update drive
3. Open the update drive on the TRT
4. Start the Java installation
5. Move the Pomcash file on the drive to the Pomcash folder that is located on the desktop
6. Hit copy and replace
7. Remove the thumb drive and plug the black USB back in
8. Scan the series of barcodes that are attached to this sheet in the following order
 - a. Enter setup, disable code 128, exit setup
9. Hit the run program in the Pomcash folder

Note: You should only do the installation after doing the collection in the event of a malfunction. Also, the version on the system startup ticket should read E1.83.



0006010

Enter Setup



0400010

Disable Code 128



0006000

**** Exit Setup**